ASSIGNMENT 3

Textbook Assignment:

"Surface Observation Equipment" (continued), chapter 2, pages 2-9 through 2-39. "Surface Observation Codes", chapter page 3-1 through 3-18.

- 3-1. Liquid-in-glass thermometers for meteorological applications should be read to what increment?
 - 1. Whole degree
 - 2. Half degree
 - 3. Quarter degree
 - 4. Tenth degree
- 3-2. You are using a wet-bulb thermometer in below freezing temperatures. After wetting the wet-bulb wick, how many minutes must you wait before reading the value?
 - 1. 1
 - 2. 5
 - 3. 10
 - 4. 15
- 3-3. What is the range of temperatures, from lowest to highest, that can be measured by an alcohol thermometer?
 - 1. -115° C to $+78.5^{\circ}$ C
 - 2. -115° F to $+78.5^{\circ}$ F
 - 3. -20°C to $+120.0^{\circ}\text{C}$
 - 4. -20° F to $+120.0^{\circ}$ F
- 3-4. Of the following statements, which one correctly identifies why you should avoid using mercury thermometers?
 - 1. Mercury thermometers are expensive
 - 2. Alcohol thermometers are better suited for meteorological and oceanographic measurements
 - 3. Mercury is prone to separation
 - 4. Mercury is a hazardous material

- 3-5. When the temperature is above 85°F, how many minutes must an electric psychrometer be allowed to acclimatize prior to use?
 - 1. 1 to 2 minutes
 - 2. 5 to 10 minutes
 - 3. 10 to 15 minutes
 - 4. 15 to 20 minutes
- 3-6. You are using an electric psychrometer at night in an unlighted area. When, if ever, should you turn on the scale lights?
 - 1. When turning on the fan motor
 - 2. Only when actually reading the temperatures
 - 3. Whenever light is needed in the observation area
 - 4. Never; scale lights are provided for calibration only
- 3-7. What is the pressure element in an ML-448/UM precision aneroid barometer?
 - 1. A Sylphon cell
 - 2. A series of gears
 - 3. An electronic circuit
 - 4. A bellows
- 3-8. A precision aneroid barometer should be read to the nearest
 - 1. 0.5 in.
 - 2. 0.05 in.
 - 3. 0.005 in.
 - 4. 0.0005 in.

- 3-9. The primary use of the marine barograph is to determine
 - 1. 3-hour pressure tendencies
 - 2. sea-level pressure
 - 3. altimeter setting
 - 4. station pressure
- 3-10. How often should recording charts be replaced on the barograph?
 - 1. Once a quarter
 - 2. Once a week
 - 3. Every 4 days
 - 4. Every day
- 3-11. What type of purple ink should you use to reink a barograph pen?
 - 1. Fountain-pen ink
 - 2. Recording ink
 - 3. Stamp-pad ink
 - 4. Ball-point-pen ink
- 3-12. What is the maximum number of indicators that may be connected to each AN/UMQ-5 wind measuring system?
 - 1. One
 - 2. Two
 - 3. Five
 - 4. Six
- 3-13. Which of the following indicators/recorders is used primarily by air traffic control personnel?
 - 1. ID-2447/U
 - 2. RD-108/UMQ-5
 - 3. ID-300/UMQ-5
 - 4. ID-586/UMQ-5

- 3-14. While operating at the standard speed, the RD-108/UMQ-5 recorder can run for approximately how many days before the chart must be changed?
 - 1. 30
 - 2. 15
 - 3. 10
 - 4. 7
- 3-15. What kind of wind is measured by the Type B-3 wind indicator?
 - 1. True
 - 2. Total
 - 3. Relative
 - 4. Magnetic
- 3-16. If the apparent winds are read on the wind indicator as 120° at 27 knots, and the ship is moving toward True North, which of the following computed true winds is most likely correct?
 - 1. 140° at 33 knots
 - 2. 090° at 23 knots
 - 3. 230° at 40 knots
 - 4. 330° at 25 knots
- 3-17. What is the purpose for depressing the trigger on the AN/PMQ-3 hand-held anemometer?
 - 1. To check calibration
 - 2. To release the wind vane
 - 3. To switch to the high scale
 - 4. To switch to the low scale
- 3-18. How often should the wind-speed transmitter unit of the AN/PMQ-3 be oiled?
 - 1. After each use
 - 2. Once per month
 - 3. Twice per quarter
 - 4. Twice per year

- 3-19. The ML-217 plastic rain gauge is used only to measure liquid precipitation.
 - 1. True
 - 2. False
- 3-20. Runway visual range may be changed by turning up the intensity of the runway lighting.
 - 1. True
 - 2. False
 - A . R-437/GMQ-10
 - B. ML-461/GMQ-10
 - C. OA-7900/GMO-10
 - D . ID-820/GMQ-10

Figure 3-A

IN ANSWERING QUESTIONS 3-21 THROUGH 3-23, REFER TO FIGURE 3-A. SELECT THE GMQ-10 COMPONENT THAT MATCHES THE DESCRIPTION GIVEN. NOT ALL RESPONSES A R E U S E D.

- 3-21. Provides a LED digital display of runway visual range in hundreds of feet.
 - 1. A
 - 2. B
 - 3. C
 - 4. D
- 3-22. The transmissometer indicator/recorder unit.
 - 1. A
 - 2. B
 - 3. C
 - 4. D
- 3-23. The transmissometer projector.
 - 1. A
 - 2. B
 - 3. C
 - 4. D

- A. DAILY
- B. WEEKLY
- C. EVERY 2 WEEKS
- D. MONTHLY

Figure 3-B

IN ANSWERING QUESTIONS 3-24 THROUGH 3-26, REFER TO FIGURE 3-B. NOT ALL RESPONSES ARE USED.

- 3-24. If the ID-353B/GMQ-10 recorder is operated continuously with the AN/GMQ-32 system, how often must the recorder chart be replaced?
 - 1. A
 - 2. B
 - 3. C
 - 4. D
- 3-25. How often must the ID-820/GMQ-10 recorder chart drive spring be rewound?
 - 1. A
 - 2. B
 - 3. C
 - 4. D
- 3-26. How often must the ID-820/GMQ-10 zero adjustment be readjusted?
 - 1. A
 - 2. B
 - 3. C
 - 4. D
- 3-27. Which of the three mode settings on the OA-7900A/GMQ-10 indicator provides runway visual range?
 - 1. NORMAL only
 - 2. NORMAL or DAY
 - 3. NORMAL or NIGHT
 - 4. DAY or NIGHT

- 3-28. When using the RO-546 recorder, you must apply the equipment correction factor to what reading(s)?
 - 1. Recorded elevation angles for solid cloud bases under 45° elevation
 - 2. Recorded elevation angles for solid cloud bases over 45° elevation
 - 3. Recorded elevation angles for fog and stratus under 25° elevation
 - 4. All recorded elevation angles regardless of cloud type or cloud height
- 3-29. In which of the following situations should a new correction factor be determined for the RO-546 recorder?
 - 1. After replacing a projector bulb
 - 2. After refocusing the projector lights
 - 3. After cleaning the detector lens
 - 4. After each of the above
- 3-30. What maintenance responsibilities, if any, do Aerographers have for the RO-546 recorder?
 - 1. Replacing fuses and adjusting the power supply
 - 2. Changing the chart paper and chart-marking stylus
 - 3. Sending the unit out for calibration
 - 4. None
- 3-31. What is the maximum range of the ML- 12 1 ceiling light projector?
 - 1. 5,000 ft
 - 2. 10,000 ft
 - 3. 12.500 ft
 - 4. 15,000 ft
- 3-32. What value does a clinometer actually measure?
 - 1. Cloud elevation angle
 - 2. Baseline distance
 - 3. Cloud height
 - 4. Height above waterline

- 3-33. Ceiling balloons provide reasonable measurements of cloud heights up to what maximum height?
 - 1. 2,000 ft
 - 2. 7,500 ft
 - 3. 12,000 ft
 - 4. 25,000 ft
- 3-34. After a 30-gram balloon is inflated, how much free lift, in grams, should the balloon have?
 - 1. 75
 - 2. 89
 - 3. 126
 - 4. 139
- A. CP-718/UM DENSITY ALTITUDE COMPUTER
- B. CP-165/UM PSYCHROMETRIC COMPUTER
- C. CP-264/U TRUE WIND COMPUTER
- D. CP-402/UM PRESSURE REDUCTION COMPUTER

Figure 3-C

IN ANSWERING QUESTIONS 3-35 THROUGH 3-38, REFER TO FIGURE 3-C. MATCH EACH HAND-HELD COMPUTER TO THE DESCRIPTION GIVEN. RESPONSES ARE USED ONLY ONCE.

- 3-35. Used to compute dew-point temperature or relative humidity.
 - 1. A
 - 2. B
 - 3. C
 - 4. D
- 3-36. Used to compute up to six different values including specific humidity.
 - 1. A
 - 2. B
 - 3. C
 - 4. D

- 3-37. Used to compute pressure altitude and altimeter setting.
 - 1. A
 - 2. B
 - 3. C
 - 4. D
- 3-38. Used to calculate a desired course and speed of a ship to recover or launch aircraft, but has other applications as well.
 - 1. A
 - 2. B
 - 3. C
 - 4. D
- 3-39. What should you do when you first become aware of an equipment outage?
 - 1. Ignore it
 - 2. Notify your supervisor
 - 3. Call maintenance personnel
 - 4. Unplug the power
- 3-40. While at sea, an equipment failure occurs that is beyond the capability of onboard technicians to repair. What maintenance resource should be used during the next in-port period?
 - 1. 3-M
 - 2. FTRs
 - 3. METEM personnel
 - 4. Naval supply system
- 3-41. Which of the following maintenance sources provides support for all shipboard equipment?
 - 1. 3-M
 - 2. FTRs
 - 3. METEM personnel
 - 4. Contractors

- 3-42. Asia is located in what WMO region?
 - 1. I
 - 2. II
 - 3. III
 - 4. IV
- 3-43. What type of code form is used only within a specific country?
 - 1. National
 - 2. Regional
 - 3. International
 - 4. Special
- 3-44. Which of the following forms is used to record shipboard weather observations?
 - 1. FMH Form-10
 - 2. CNMOC Form 3144.1
 - 3. CNMOC Form 3140/12
 - 4. CNMOC Form 3141/3
- 3-45. If you discover an error in an observation after it has just been transmitted, what, if anything, should you do?
 - 1. Erase the incorrect data on the observation record and enter the correct data
 - Line out the incorrect data on the observation record and enter the correct data in red only
 - 3. Line out the incorrect data, enter the correct data in red, transmit a correction, and enter the transmission time of the correction
 - 4. Nothing
- 3-46. At the end of each month, observation forms must be forwarded to which of the following commands?
 - 1. FNMOC, Monterey, CA
 - 2. NLMOD, Pensacola, FL
 - 3. FNMOD, Asheville, NC
 - 4. CNMOC, Bay St. Louis, MS

- 3-47. If dangerous weather such as a tornado is seen, what type of observation should be transmitted?
 - 1. METAR
 - 2. SNYPOTIC
 - 3. SPECI
 - 4. RECORD SPECIAL
- 3-48. Which of the following observations should contain 3-hourly additive data?
 - 1. 1300Z
 - 2. 1500Z
 - 3. 1800Z
 - 4. 1750Z

(actual observation)

METAR MXXX 221100Z 21017G34KT 2SM

BKNO15CB OVC040 18/17 A2991 RMK FRQ LTGCC W

TS W MOV NE SLP133;

(symbolic format for this case)

METAR CCC YYGGggZ dddffGfmfmKT

VVVVSM w'w'

 $\begin{array}{lll} N_sN_sh_sh_sh_s & N_sN_sh_sh_sh_s & T'T'/T'_dT'_d & AP_HP_HP_HP_H\\ (supplemental); \end{array}$

(actual observation)

METAR MYYY 221056Z 07005KT 1/2SM R03L/2400FT

FG VV005 15/15 A2992 RMK SLP132;

(symbolic format for this case)

METAR CCCC YYGGggZ dddffKT VVVVSM

 $RD_RD_R/V_RV_RV_RV_Rft$ w'w' $VVh_sh_sh_s$ $T'T'/T'_dT'_d$

 $AP_HP_HP_HP_H$

(supplemental);

Figure 3-D

IN ANSWERING QUESTIONS 3-49 THROUGH 3-54, REFER TO THE METAR CODED REPORTS FOR STATIONS MXXX AND MYYY IN FIGURE 3-D.

- 3-49. What is the wind direction at station MXXX?
 - 1. 340°
 - 2. 210°
 - 3. 170°
 - 4. 080°
- 3-50. What is the horizontal surface visibility reported at station MYYY?
 - 1. 1/2 statute mile
 - 2. 1/2 statute meter
 - 3. 15 nautical miles
 - 4. 2,400 feet
- 3-51. What is the runway visual range reported by station MYYY?
 - 1. 300 feet
 - 2. 2.400 meters
 - 3. 2,400 feet
 - 4. 0300 variable 2,400 feet
- 3-52. What weather is occurring at stations (a) MXXX and (b) MYYY?
 - 1. (a) Thunderstorm with rain
 - (b) smoke
 - 2. (a) Thunderstorm with rain
 - (b) fog
 - 3. (a) Thunderstorm with hail
 - (b) fog
 - 4. (a) Thunderstorm with hail
 - (b) smoke
- 3-53. What is the sea level pressure at MXXX?
 - 1. 29.91 in.
 - 2. 29.91 hPa
 - 3. 1013.3 in.
 - 4. 1013.3 hPa

- 3-54. How much sky cover is present over station MYYY?
 - 1. 0/8
 - 2. 1/8
 - 3. 8/8
 - 4. Unable to determine; no significant clouds cover was reported
- 3-55. In METAR observations, temperatures are reported to the nearest
 - 1. tenth degree Fahrenheit
 - 2. tenth degree Celsius
 - 3. whole degree Fahrenheit
 - 4. whole degree Celsius
- 3-56. When you are reporting altimeter settings, what is the meaning of "A," as in A2992?
 - 1. The altimeter setting is an approximation
 - 2. The altimeter setting is the maximum for the day
 - 3. The altimeter setting is in inches
 - 4. The altimeter setting is in hectopascals

- 3-57. Unlike shore stations, the METAR code aboard ship is used only to record data, not to encode data for transmission.
 - 1. True
 - 2. False
- 3-58. International code FM 12-XI SYNOP is used to report which of the following observations?
 - 1. Land synoptic
 - 2. Ship synoptic
 - 3. Land aviation
 - 4. Ship aviation

(actual observation)

AAXX 18004 72409 21660 72214 10147 20131 39986 49991 54000 70500 84121 91749 333 10147 20086 60001 70005;

(symbolic format for this case)

Figure 3-E

IN ANSWERING QUESTIONS 3-59 THROUGH 3-62, REFER TO FIGURE 3-E AT THE TOP OF THIS PAGE. REFER TO THE REGION IV LAND-STATION SYNOPTIC REPORT.

- 3-59. What is the station's block/station number?
 - 1. 72409
 - 2. 21660
 - 3. 72213
 - 4. 70005
- 3-60. What is the wind direction?
 - 1. 072°
 - 2. 130°
 - 3.210°
 - 4. 220°
- 3-61. What is the dew-point temperature?
 - 1. 14.7°F
 - 2. 14.7°C
 - 3. 13.1°F
 - 4. 13.1°C
- 3-62. In WMO Region IV at 0000Z, what maximum and minimum temperatures are reported following the 333 indicator?
 - 1. Previous 12-hour minimum and previous 18-hour maximum
 - 2. Previous 24-hour maximum and previous 12-hour minimum
 - 3. Previous 12-hour maximum and previous 18-hour minimum
 - 4. Previous 24-hour maximum and minimum

- 3-63. If a station within the United States reports code groups after a "555" indicator, which of the following publications would provide the information necessary to decode these groups?
 - 1. WMO Pub 306, Vol 1, International Codes
 - 2. NAVMETOCCOMINST 3141.2
 - 3. FMH-1 (Federal Meteorological Handbook Number 1)
 - 4. FHM-2 (Federal Meteorological Handbook Number 2)
- 3-64. What publication is used to convert the IRCS to the ship's name and country of registration?
 - 1. FMH-2
 - 2. FMH-1
 - 3. ACP-100
 - 4. WMO Pub 306, Vol 1

The maritime data section of an actual ship synoptic report reads:

22212; 00123 20504 30207 40806 51004 The symbolic format of this section is: 222D_SV_X 0S_ST_WT_WT_W 2P_WP_WH_WH_W 3d_{WI}d_{WI}d_{W2}d_{W2} 4P_{WI}P_{WI}H_{WI}H_{WI} 5P_{W2}P_{W2}H_{W2}H_{W2};

Figure 3-F

IN ANSWERING QUESTIONS 3-65 THROUGH 3-69, REFER TO FIGURE 3-F.

- 3-65. Which group reports sea-surface temperature?
 - 1. 22212
 - 2. 00123
 - 3. 20504
 - 4. 30207
- 3-66. What is the sea-wave height and sea-wave period?
 - 1. 4 ft, 5 sec
 - 2. 5 ft, 4 sec
 - 3. 7 ft, 5 sec
 - 4. 8 ft, 4 sec
- 3-67. What is the primary swell-wave direction?
 - 1. 020°
 - 2. 030°
 - 3. 070°
 - 4. 080°

- 3-68. What is the secondary swell-wave period?
 - 1. 4 sec
 - 2. 6 sec
 - 3. 8 sec
 - 4. 10 sec
- 3-69. What is the primary swell-wave height?
 - 1. 4 ft
 - 2. 7 ft
 - 3. 10 ft
 - 4. 16 ft
- 3-70. What code form do meteorological buoys moored near coastal harbors use to report position?
 - 1. Land Synoptic (SYNOP)
 - 2. Ship Synoptic (SHIP)
 - 3. SPECI
 - 4. METAR